



KLIX *Eco Cup*

Case Handling and Storage

The case of product should always be transported and stored in the upright position and not on its side. Product removed from the case should also be stored with the cups upright.

MACHINE LOADING PROCEDURE

Once you have removed the stick of cups from the sleeving you will see that there is a band round the stick to stop them from falling apart in the sleeving.

Take the stick of cups whilst holding the bottom cup remove the band. If you do not hold the bottom cup, the cups will separate and fall from the stick.

Do not put plastic and paper cups in the same carousel stack.

Remove the top bung from a stack of cups in the carousel

Place the new stick into the stack which you have removed the bung

Pull the top section of the stack so that the cups are partially removed from the carousel to load more cups (Pictures in Figure 1).

Push the stick back into the carousel (Red Arrow) and ensure all cups are in the carousel.

Position your hand underneath the entire stack of cups in the carousel position (Figure 2). Lift the entire stack up towards the top of the carousel until the rim of the bottom cup is just visible above the baseplate. Carefully lower the stick back so that the bottom cup rests back on the scrolls.

FIGURE 1



FIGURE 2

